

SERIES 167 – BUILD-IN COOKING HOB MODEL:- S~HB16746Y

FITTING INSTRUCTIONS FOR GLASS LID

- 1. Rotate the two hinges into the open position. The hinge spring tension is quite strong, the use of a flat blade screw driver in the hinge 'glass slot' will assist with this operation.
- 2. Rotate one full turn anticlockwise the two glass retaining screws.
- 3. Check the plastic sleeve is located correctly in each hinge.
- 4. Insert the glass lid into the hinges, the small clear panels on the bottom edge of the glass will assist with alignment to the hinges.
 - Important The printed face of the glass MUST be on the underside of the glass when the lid is shut.
- 5. Rotate clockwise both glass retaining screws and apply a torque of 15 lbf-in to lock the glass in position.
- 6. Carefully close the lid and verify both left and right gaps, between the glass and trim, are equal.

NOTE:- If the side gaps are unequal realigned the glass by repeating above sequence.

